



---

Real Time Remote Control and Monitoring

# **RealiteQ User Interface (UI)**

**User manual**

**PC version**

## Table of contents

<b>1. Introduction .....</b>	<b>Page 4</b>
<b>2. Getting started .....</b>	<b>Page 4</b>
2.1. Login .....	Page 4
2.2. Download UI project configuration .....	Page 5
2.3. User Interface (UI) .....	Page 5
<b>3. Working with Node tree .....</b>	<b>Page 6</b>
3.1. Tree strip structure .....	Page 7
3.2. Group Strip .....	Page 9
3.3. Point strip .....	Page 10
3.4. Alarm strip .....	Page 10
3.5. Searching the Node tree .....	Page 11
3.6. Working with the Bread Crumbs .....	Page 12
<b>4. Map .....</b>	<b>Page 12</b>
<b>5. Process screen .....</b>	<b>Page 13</b>
<b>6. Table reports .....</b>	<b>Page 15</b>
6.1. Node report.....	Page 15
6.2. Predefine reports .....	Page 17
6.3. Current alarms .....	Page 17
6.4. Group alarms historical log .....	Page 19
6.5. Node alarm historical log .....	Page 20
<b>7. Trend graphs report .....</b>	<b>Page 20</b>
<b>8. Project download and settings .....</b>	<b>Page 22</b>
<b>9. Project configurations and edit .....</b>	<b>Page 23</b>
<b>10. Map – edit map stations location .....</b>	<b>Page 23</b>
10.1. Locate .....	Page 24
<b>11. Edit Screen list .....</b>	<b>Page 25</b>
<b>12. Edit Reports &amp; Trends list .....</b>	<b>Page 25</b>
12.1. Report & Trend template .....	Page 26
<b>13. Edit project nodes .....</b>	<b>Page 27</b>
<b>14. Edit Users .....</b>	<b>Page 29</b>
<b>15. Draw editor .....</b>	<b>Page 31</b>
<b>16. Upload to COMP .....</b>	<b>Page 32</b>

## Appendixes


<b>1. Address space .....</b>	<b>Page 33</b>
<b>2. Filter .....</b>	<b>Page 34</b>
<b>3. Formats .....</b>	<b>Page 35</b>
<b>4. Source field .....</b>	<b>Page 36</b>

## **Version changes**

1.0.00	2011-10-15	First draft
1.1.01	2012-02-01	Updates new functionalities
1.2.01	2013-05-01	Updates new functionalities
1.3.01	2015-01-01	Updates new functionalities
1.4.01	2018-01-25	Updates new functionalities

## 1. Introduction

The UI (User interface) can be run on any modern browser such as MS Edge or Explorer, Fire-Fox, Chrome Safari etc. that are running on computer, tablet or smart-phone. The UI pages can include real-time and historical data received from the RealiteQ COMP (Central Online Management Portal).



## 2. Getting Started

### 2.1. Login:

Open your browser and type URL. In this manual we will work with demo project <http://ui.realiteq.net>. Login with username = **ui** and password **ui**.

Login

Username

Password

Strength

very weak - score = 10%

Password used for more than 90 days, for safety reasons it is recommended to replace it!

Login


After successfully login to the COMP, the screen will change and the communication status will change to ok.




The login is valid for one hours of working. The page keeps the last security key even if you are going out for a short period (10 minutes) so you can browse back the page without re-login. For security reasons do not forget to logout before you are closing the page permanently.



## 2.2. Download UI project configuration:

Click on  button (You will find it on the right bottom corner of the screen) to open the download-project screen.




Click on **Set All** button, then, when all options are checked, click on **Apply**, Confirm with **OK** and then click on **Return** button.

## 2.3. User interface (UI):




The UI consists of two parts:

- On the left side is the project *nodes tree*.
- On the right side, you can view: process graphic screens, unit's location map, alarms status, alarms historical log, variable historical log in a table or trend format.

One way to determine what is shown on the right is using the *navigate buttons*:



Navigate buttons:

-  Map button - Displays unit's location on map.
-  Screens button - Displays process screens
-  Reports button - Displays project table reports.




Trend graph button- Displays project trend graph reports.



Current alarm buttons - Display project current active alarms table.

**Note:** The image button displays a textual tool-tip when the mouse moves over it. The background color of the pointed button will change to dark gray too. The tool-tip yellow text window is shown in a delay of one second and disappears after maximum five seconds. The tool-tip window disappears also when you click on the button or the mouse is out of the button area.

### 3. Working with Node Tree



You can control the tree side width by dragging the splitter. You can close/open the window side by clicking on the splitter button.

#### Nodes:

Typical project data structure:

```
project
  unit 1
    group1
      item 1
      .....
      item n
    group n
  unit n
```

A *node* is a single variable that has a single state at any given time. A node is referenced using a node path (much like a directory path in a computer). All the project nodes are related to each other and are arranged in a hierarchical tree-like structure called the namespace, at the top of which is the root node. A node can have zero or any number of sub-nodes.

There are three types of nodes:

- Group – (Group of nodes). Use to improve projects displaying performance.

A unit sign-in the COMP and takes ownership of a group of nodes, for instance /unit1. All sub-nodes residing under /unit1 will henceforth to be updated by the unit.

- Point - A variable or manipulated value.
- Alarm – Unit alarm or manipulated alarm node.

The components of a node path are delimited by forward slashes. Node's paths make it easy to refer to a node by providing a uniform and universal format.

*Example: /unit1/alarm/hhlevel*

A node includes:

- Path – (Node path). One word, only standard letters and numbers are allowed. For node that reflects variables from a producer, only names of producer variable are allowed.
- Tag-name – (Node tag-name). Normally one descriptive word.
- Description – Node description.
- State – Includes: value, quality, type and stamp.

#### **States:**

A node state represents the condition of a node at a specific time. A state has the following attributes:

- Value – The node's value.
- Quality – The condition of the value:

Text	Color
Unknown	gray
Good	Green
Bad	Red
Invalid	Red
forced	Gray
Simulated	Gray

- Data type – An optional number denoting the value's data type: text, number (integer or float) or Boolean (On\Off).
- Stamp – The time and date the item state was encountered.

All state transitions can be recorded on a historical states table and can be displayed by the historical trend\table displays.

### **3.1 Tree strip structure**

Each project node is displaying in a separate strip.

Icon	Path	Tag-name	Description	State Value
	b3107	- valve	Hypo valve	<u>Off</u>
	r1503	- Power	Power consumption	<u>13</u>

Gray button means: "node has a history" and clicking on its icon button will open node history on the right side of the window.

Click the icon button or the node button load different history tables or screens:

- Clicking on icon button of:

- Group node – Displays group graphic screen (if available).
- Alarm node – No function.
- Point node – Node with history, displays log history in trend format. Node without history no function.

- Clicking on path button of:

- Group node – Displays group current alarms table.
- Alarm node – Displays node alarm history.
- Point node – Node with history, displays log history in table format. Node without history - no function.

Writeable node state value appears to underline. Clicking writeable node value opens write dialog box. There are two kinds of write dialog window one for numerical value and one for On/off set value. The upper part displays the online current node state. The lower part is used to modify the node state value.

/icex/r1511

Flow - Flow in (m3)

Current value: 67.0 m3/h

Stamp time: 11/09/2011 07:36:10

Edit value:

Write

Close

/icex/b3106

Valve - XD3897 valve

Current value: On

Stamp time: 12/09/2011 08:51:49


On

Off

Close

The icon button, path button and value display a textual tool-tip when the mouse moves over them. The cursor type and the background color of the pointed button will change too. The tool-tip yellow text window is shown in a delay of one second and disappears after maximum five seconds. The tool-tip window disappears immediately if you click on the button. Moving to point on the tool-tip window area will keep the tool-tip window open.


Pointing over the path opens the tool-tip window displaying the full path.



You can copy the full path by moving inside the tool-tip to keep it open and then just do a simple select and copy.



Pointing over the node icon or value opens the tool-tip window displaying the node description and status.



Moving over the tool-tip windows will keep it open.

Navigate buttons:



Map - Displays unit's location map. It appears only in the group node tools-tip. The button will appear only for groups that set to appear on the map. The map center will be located on the group location.



Screens - Displays process screens. It appears only in the group node tools-tip. The button will appear only for groups that got process screens.



Reports - Displays project table reports. In group node tool-tip: The button will appear only for groups that got predefines reports. In point or alarm node tool-tip: The button will appear only for nodes that preset to collect history.



Trend graph - Displays project trend graph reports. In group node tool-tip: The button will appear only for groups that got predefines reports. In the point node tool-tip: The button will appear only for nodes that preset to collect history.



Current alarm- Displays project current active alarms table. Appears only in group node tool-tip



Alarm history – Displays node alarm history. The button always appears in a group node tool-tip and for alarm node that preset to collect history.

Buttons in the node icon tool-tip displays the information in the window right side buttons in the node value tool-tip display's information inside the tool-tip window.

### 3.2 Group strip





- Show/hide group node.



Group - Group of nodes



Connected unit - Unit group connection ok. Quality status = good. Text status appears in green color.



Disconnected unit - Unit group not connected. Quality status bad or unknown. Text status appears in red color.



Alarms group or unit with alarms - Quality status = good. Text status appears in green color.

Available unit node values: connected (green color), unconnected (red/brown color). Clicking the group icon opens the group process screen (if there is) and the tree focuses to display only the unit tree.

Clicking the node path opens the group current active alarms table.

### 3.3 Point strip

	<b>b3106</b> - Valve XD3897 valve	<u>Off</u>
	<b>b3107</b> - valve Hypo valve	<u>Off</u>
	<b>r1503</b> - Power Power consumption	<u>16</u>



Unknown - On\Off point in "unknown" or "bad" state value. Text appears in gray.



Off - On\Off point in "Off" state value. Text appears in yellow.



On - On\Off point in "On" state value. Text appears in green.



Unknown - Numerical point in "unknown" state value. Text appears in gray



Good - Numerical point in "good" state value. Text appears in green.









Bad - Numerical point in "bad" or invalid state value. Text appears in red.

If "point has a history" sign appears, clicking on the node icon displays the *node history trend* graph and clicking on the path button displays the *node history table*.

### 3.4 Alarm strip

Alarms are events that can be set to be triggered upon a certain condition which requires the attention of the operator. The alarm's conditions are set, in RealiteQ-COMP during the project setting. The alarm's conditions are constantly evaluated by the RealiteQ-COMP. When a new alarm occurs, the COMP updates the RealiteQ - Consumer (Viewer).



-  Unknown - Alarm in unknown status. Value = unknown in gray color
-  Inactive - Alarm inactive. Value = OK in blue color.
-  Inactive unack - Alarm inactive and unacknowledged. Value = unack-OK in green color.
-  Active ack - Alarm active and acknowledged. Value = ack-On in red color.
-  Active unack - Alarm active and unacknowledged. Value = unack-On in red color.

If "alarm has a history" sign appears, clicking on the alarm icon or path will display the alarm history.

If the alarm was defined for user acknowledge the alarm value will appear to underline. Click the value will be acknowledges the alarm.

Alarms that were set to silent will appear with a "silent" suffix.

### 3.5 Searching the nodes tree




Search shows all the tree nodes that their path, tag-name or description included the search criteria. The system displays the first fifty nodes. To view more scroll to the end of the list and click on the "View more". To search nodes,

enter the search criteria  and then click  the search button. To return to display the normal

tree click the Bread crumbs root button.

### 3.6. Working with the Bread crumbs


The Bread crumbs provide an easy way to see where you are on the tree and allow you to jump back to any stage in the tree with a single click.



## 4. Map

The map shows the location and status of the project stations. The map can be displayed in a street or satellite format (see upper left corner of map display). The user can control the map zoom with mouse wheel or with the + and – buttons in lower left side of display. You can drag the map display to any direction. You also can expend the map to full display (upper right corner icon). In this case ESC will return to normal view.

On map you can see also status of some of the nodes and alarms.



Station status:



Disconnected



Connected




Connected with at least one active alarm.

Clicking station status icon shows the station process screen on the right side (If such a screen available). The tree side displays the specific station tree. Move over a station's icon open group tool-tip window (for more details see paragraph 3.1)

## 5. Process screen

RealiteQ-UI screens are the primary elements of the User interface. They present the operator real-time information in a graphical form and allow him to change and control field values. This can be done by either entering numerical values using the keyboard or by direct manipulation using the mouse, clicking and dragging graphical elements.



RealiteQ-UI offers a powerful screen engine capable of presenting rich, high-quality graphics to the operator. Graphical elements can be connected to real-time values by means of links. Links can be programmed in a variety of ways to control every aspect of the display, including changing colors, visibility, position, etc. Links can be used to define actions related to mouse operations, such as changing a value, opening windows etc.

A project may contain any number of screens which can be shown on a request.

The top bar contains a zoom panel on the right, allowing the operator to zoom in and zoom out the displayed picture.



Redraw – Redraw the current screen.



Zoom in



Zoom out



Actual – Reset to actual size.



Fit – Fit to the container size.

Bottom bar button: Select the display screen.



Previous – Display the previous screen.




- Select – Display the selected screen




Next – Display the next screen.

Positioning the mouse over a link displays tool-tip with the current node state.




Positioning the mouse over writeable graphical elements will change the mouse cursor to a hand cursor.

A hand cursor indicates that clicking the element will perform an action, such as set, reset and toggle an element, switching to a screen, or opening an edit dialog window.



Clicking writeable node value opens write dialog box. The current edit node marks with four black squares. There are two kinds of write dialog window - one for numerical value and one for On/Off set value. The upper part displays the online current node state. The lower part is used to modify the node state value.





## 6. Table reports

RealiteQ-UI offers a comprehensive suite of tools for viewing historical values in tables format.

### 6.1 Node report

Item history is database tables containing historical process data that were collected by the RealiteQ-COMP. Each row in the item history contains a time-stamp, quality and value. The Reality-Server logs record only when the item status changes.

Item history is database tables that contain historical process data that were collected by the RealiteQ-COMP. Each row in the item history contains a time-stamp, quality and value. The RealiteQ-Server logs record only when the item status changes.

Date	Value
17/09/2011 17:30:32	45.0 m3/h
17/09/2011 17:30:32	45
17/09/2011 17:30:30	23.0 m3/h
17/09/2011 17:30:30	23
17/09/2011 17:30:27	11.0 m3/h

Clicking on the tree node path displays the node log history in the right pane of the screen.

On opening the UI displays the current-day samples log. The data is displaying in descend order - the end date displays on top of the table.

#### Header:

First row: Item path, tag-name and description.

For example:

/icex/ r1503 – Power - Power consumption.

Second row: Item last sample: Value, Quality, Stamp.

For example:

Value = 23.4 C, Quality = Good, Sample = 2008/09/01 10:45:10

Third row: Type of the table, Start and end date and number of record of the displayed period

Button functions:



Previous – change end date to previous day



Trend – display current data in trend graph format




Export - Exports displaying data



Print – Prints table



Tabs – display table in new tab or window



Date – select end date from calendar dialog



More – Retrieve and attach to the end table data for another day




Now – change End Date to Now




Next – change End Date to Next day

Click on the date button opens a date picker dialog box:




Click on the export button opens a dialog window showing the current table data in CSV format allowing you to copy and save the data.





## 6.2. Predefine report

The user can define reports containing up to eight variables. The UI will display the report in the selected interval. The RealiteQ-COMP supplies for each stamp the last-known value. See paragraph 12 how to define a report template and how to configure the reports list.



Date	Pump run	Power	Level	Flow
17/09/2011 19:25:00	false	15	47.0 m	45.0 m3/h
17/09/2011 19:20:00	false	15	47.0 m	45.0 m3/h
17/09/2011 19:15:00	false	15	47.0 m	45.0 m3/h
17/09/2011 19:10:00	false	15	47.0 m	45.0 m3/h
17/09/2011 19:05:00	false	15	47.0 m	45.0 m3/h

Clicking the table button on the tree toolbar displays the current report log history in the right pane of the screen. On opening the UI displays the current-day log. The data is displaying in descend order - the end date displays on top of the table.


Buttons:

For details about history table standard buttons see in node report paragraph 6.1.

17/09/2011

Interval – Set the interval between the display sample


To select interval between display samples, click on interval button and select the right interval.



Bottom bar button: Select the display report.



- Previous – Displays the previous report.



- Select – Displays the selected report



- Next – Displays the next report.

## 6.3. Current alarms

Alarms are events that can be set to be triggered upon a certain condition which requires the attention of the operator. The alarm's conditions are set, in Reality-COMP during the project setting. The alarm's conditions are constantly evaluated by the Reality-COMP. When a new alarm occurs, the COMP updates the Reality-Consumer (Viewer).

The project current active alarm button can appear in two icons:




Alarms OK - No active current alarms



Alarms active - At least on active alarm

Clicking the button displays the current project active alarms tables.



Clicking on a group item path button opening the group active alarms table.

The screen-shot above is showing four open alarms:

AI01 – On, the alarm was not setting to user acknowledge.

AI02- On and already acknowledged by the user.

AI03- On but still do not acknowledged by the operator.

AI04 - Off and not acknowledged by the operator yet.

AI05 – Off.

The project active current alarm button in active status and the icon of the parent group of the alarms are appearing in alarm active icon.

The Current alarms window provides a summary of all currently active alarms.

Ack Sil C A S							
/: - Home							
value: Quality: Unknown Stamp: 30/05/2011 19:24:31							
Current alarms : 4 active alarm							
Path	Tagname	Description	State	Start	End	Ack	By
/icex/alarms/al03	Pit	High level	active, acknowledged	17/09/2011 19:22:10		17/09/2011 19:22:30	david
/icex/alarms/al02	M1	M1 No feedback	active, acknowledged	17/09/2011 19:22:10		17/09/2011 19:22:28	david
/icex/alarms/al01	M1	M1 Overload	unacknowledged	17/09/2011 19:10:47	17/09/2011 19:22:18		
/icex/alarms/al05	M1	M2 Overload	active, unacknowledged	17/09/2011 19:22:10			

A current alarm is an alarm which condition evaluates to be true. Alarms which must be acknowledged will be displayed as current even after their condition no longer evaluates to be true, if they are not acknowledged.

The user can use the silence feature to get rid of alarms, which are of no interest at the moment. Clicking the Refresh button will restore all active alarms to the list. Acknowledging alarms can be done for all active alarms or for individual alarms.

The Current alarms displays the following information for each alarm:

**Path** - The alarm path. Click the path switch to display specific alarm log.

- Tag-name** - The Alarm tag Name.
- Description** - The alarm description.
- Status** - The alarm status: active, active unacknowledged, active unacknowledged inactive and inactive unacknowledged.
- Started** - The date and time the alarm started.
- Ended** - The date and time the alarm ended.
- Ack.** - The date and time the alarm acknowledged.
- By** - The user name who acknowledge the alarm.

The latest alarm is displayed at the top of the window. Alarm will disappear from the Current alarm window only after alarm ended and acknowledged.

Buttons:

For details about history table standard buttons see **Node report paragraph 6.1.**



Refresh – Refresh display. Force to read alarm status from the Reality-COMP.



Acknowledge all - Acknowledging alarms can be done for all alarms, or for specific alarms. To acknowledge all alarms, click acknowledges-all buttons. To acknowledge a specific alarm, can be done in the alarm log display or from the tree display.



Un-silence – Un-silence all alarms. Specific alarms can be silenced; silence is removing the alarms from the Current alarm window. Silence specific alarms can be done in the alarm log display.



History table - display alarms log history table

## 6.4. Group alarms historical log

Alarms can also be logged to the alarm log, a database table automatically maintained by Reality-COMP The alarm logged maintains information such as alarm start and end times, acknowledge time and the duration of the alarm.

/ : - Home							
value: Quality: Unknown Stamp: 30/05/2011 19:24:31							
Alarms history : 15/09/2011 - 17/09/2011 : 2 records							
Path	Tag-name	Description	Start	End	Duration	Ack. by	Ack. Stamp
/icex/alarms/al02	M1	M1 No feedback	17/09/2011 19:10:47	17/09/2011 19:10:52	00:00:04	david	17/09/2011 19:11:03
/icex/alarms/al01	M1	M1 Overload	17/09/2011 19:10:06	17/09/2011 19:10:12	00:00:06		

The alarms historical log displays the following information for each alarm:

Path - The alarm path. Click the path switch to display specific alarm log.

- Tag-name** - The Alarm tag Name.
- Description** - The alarm description.
- Start** - The date and time the alarm started.
- End** - The date and time the alarm ended.
- Duration** - The alarm duration.
- Ack. by** - The acknowledge user name.
- Ack. Stamp** - The date and time the alarm acknowledged.


Buttons:

For details about alarm history table standard buttons see in node report paragraph 6.1.



Current alarms – Display current alarms table.

## 6.5. Node alarm historical log



The alarms historical log displays the following information for each alarm:

- Start** - The date and time the alarm started.
- End** - The date and time the alarm ended.
- Duration** - The alarm duration.
- Ack. by** - The user name who acknowledge the alarm.
- Ack. Stamp** - The date and time the alarm acknowledged.

Buttons:

For details about alarm history table standard buttons see in node report, paragraph 6.1



Acknowledge - Acknowledging specific alarm.



Silence - Silence specific alarm. silence is removing the alarms from the Current alarm window.




Un-silence - Un-silence specific alarms.

## 7. Trend graph reports

Each item with "Save to History" setting can be visualized in charts. Up to 8 items can be plotted at once against time. Charts can display as little as a single minute of values or as much as a year of values, letting you zoom-in and out, move backward and forward in time.

The item logs stores in the RealiteQ-COMP and can display by the RealiteQ-UI.



There are two types of graph:

Node – Display the node history in trend graph format. Display single trend.

Report – Display predefined reports in a trend graph format. Display up to eight trends.


Click the trend button displays the report trend graphs. Click the node icon in the tree displays the node trend.

Drag inside the graph box measures values at specific points in time.

Buttons function:

	Previous	– Scroll backward, full timescale duration.
	Half previous	– Scroll backward, half timescale duration.
	Adjust	- Redraw trend adjusting to the space size.
	Table	– Switch to table display.
	Tab	- Display trend graph in new tabs or window.
	24 Hours	Time scale – Select display timescale duration
	18/09/2011-18/09/2011	Jump & timescale – Select date and time scale duration
	Now	– Display the current time trend.
	Half next	– Scroll foreword, half timescale duration.
	Next	– Scroll foreword, one full timescale duration.

For report trend display there is a bottom toolbar to select the display report trend graph.



## 8. Project download and setting

The modern browser allows web applications to synchronize data into a local data store (Local storage) and then allow the web applications to use this data online. The UI application use these features to keep the user project setting locally. The project managers normally prepare the general project screens and reports and then upload them to the COMP. The project UI clients can now at any time download the project setting to their browser local storage. The UI clients can change their screens, reports and other setting locally.



### Notes:

- Only user with administrator privilege can upload the project to the COMP.
- User will need to load the settings once, **only the first time you log in to the project.**
- All the further user modification affects only his project setting in his browser local storage.
- **Caution:** the download data will erase your local project private setting.
- Each project saves in a different local storage. (there is private storage for each URL).


**Caution:** Some browsers clear the local storages too when you ask to clear the browsing history. Always keep the export backup of your private project setting.

### Download

- Map – Download map center, map type and unit's path, location and description.
- Reports – Download reports/trends template and reports/trend list.
- Templates – Downloads Report and trends templates
- Screens – Download screens template and screens list
- Draws – Downloads graphical displays of the project

To download set the necessary option and then apply.

**Note:** When you download project, especially for first time you log on it, you can use button Select All

 to download all elements of the project with one click.

### General

Clean local storage: Check to clear the project local storage.

Root path: Set according to the user read path privilege. Remarks:

- The root-path will affect the way the project node's tree is displayed. The root button in the crumbs-bread bar is showing the root-path.
- The root-path will affect the download procedure too. The UI will download only the authorized user screens, reports and units.

If your privilege only on part of the project you should first need to set the node path, then apply and reload and only then set the necessary option and apply.

## 9. Project configuration and edit



**Map:** Configure the map type and center. Set the unit's location path and description.

**Screens:** Configure the screen's list, included: path offset, description and draw template.

**Reports:** Configure the report's/trend's list, included: path offset, description and report template. Configure report templates.

**Nodes:** Add, delete and modify project nodes.


**Users:** Add, delete and modify project users.

**Editor:** Draw graphic editor.

**Upload:** Upload project setting to the COMP.

## 10. Map - Edit map and stations location

The map shows the location and status of the project stations. The map can be display in a **street** or **satellite** format. The user can control the map zoom with + and - buttons and can drag the map display to any direction.



Return Import Export Locate

Edit map details and markers

Road map: ☒ Zoom: 7

Center Lat: 40.21713 Lon: -74.71104

Del	Path	lat	lon	Label
del	/icex/alarms/al01	41.04143	-73.99693	
del	/icex/bits/b16385	41.58385	-74.01890	
del	/icex/registers/r1511	41.32221	-74.01889	
del	/icex	40.76998	-73.96630	icex1

General map setting:

**Road map** – Map types: road map or satellite picture.

**Zoom** – Set the initial map zoom.

**Center LAT, LON**– Latitude and Longitude of the map center location. The locate button opens the map and allows the user to drag and set the map center to their exact location.

All map parameters can change online: switching between road map and satellite, zooming in or out and dragging the map center. The runtime restores button displays the map in the initial parameters.




The map configuration table displays the following information for each unit:

- Path** – Unit path. You can set the path of alarm or point node too to see their values on map
- LAT, LON** – Latitude and Longitude of the unit's location. The locate button opens the map and allows to drag and set the units to their exact location.
- Label** – Unit description appears below the unit icon.

Buttons:


- Return** – Return to the main edit menu
- Import** – Import map details from a text file. You can use this option to restore the map details from a backup text file.
- Export** – Export the map details to a text file for backup, text edits or for sharing setting with other users.



Click on the text area to select and copy the data to your text editor. You also can edit the export text file: add, delete and modify rows. Caution: Keep the data structure otherwise you will not be able to import the data to the UI.

- Locate** – Open map for dragging the unit to their exact location.
- Add** – Add unit row.
- Delete** – Delete unit row.
- Save** – Save changes to local storage.

## 10.1 Locate





Locate screen allow dragging the units to their exact location, to drag the map center to the right position and to set the suitable map resolution.

Buttons:

**Return** – Return to map menu

**Save** – Save changes to local storage.

## 11. Edit Screens list

The screens list ties between the screens and their prefix **Path** (unit), draw **No.** and their **Description**.

Return Import Export Add Save				
Del	Path	No.	Offset	Description
del	/icex	1	<input checked="" type="checkbox"/>	Computer screen
del	/icex	2	<input checked="" type="checkbox"/>	Mobile screen


The screens list configuration table displays the following information for each screen:

**Path** – The offset screen path.

**No.** – Draw template number

**Offset** – When checked - Add the path field as a prefix to each draw template link path. For example: if the screen offset path = /icex1 and offset = check and link item variable path = r1501 then the online item full path will be: /icex1/r1501.

**Description** – The screen description will appear at the bottom bar of the screen.



Buttons:

**Return** – Return to the main edit menu.

**Import** – Import screens list from a text file. You can use this option to restore the screens list from a backup text file.

**Export** – Export the screens list to a text file for backup, text edits or for sharing setting with other users.

**Add** – Add screen row.

**Delete** – Delete screen row.

**Save** – Save changes to local storage


## 12. Edit Reports & Trends list

The reports list ties between the reports and their path (unit), template and description.

Return Template Import Export Add Save				
Del	Path	No.	Offset	Description
del	/icex	1	<input checked="" type="checkbox"/>	Pump station report
del	/icex	2	<input checked="" type="checkbox"/>	Description

The reports list configuration table displays the following information for each report:

- Path** – The offset report path.
- No.** – Report template number.
- Offset** – Check - Add the path field as a prefix to each report template variable path. . For example: if the report offset path = /icex1 and offset = check and item variable path = r1501 then the online item full path will be: /icex1/r1501. .
- Description** – The report description will appear at the bottom bar of the report or trend.



Buttons:

- Return** – Return to the main edit menu.
- Import** – Import report list from a text file. You can use this option to restore the reports list from a backup text file.
- Export** – Export the reports list to a text file for backup, text edits or for sharing setting with other users.
- Add** – Add report row.
- Delete** – Delete report row.
- Save** – Save changes to local storage

## 12.1 Report & Trend Template

The user can define reports and trends containing up to eight variables. The UI will display the report in a selected interval and up to 8 items can be plotted at once against time.

Active	Path	Description	Minimum	Maximum	Unit	Axis
<input checked="" type="checkbox"/>	/b3100	Pump run	0	5		<input checked="" type="checkbox"/>
<input checked="" type="checkbox"/>	/r1503	Power	0	1000	KW	<input type="checkbox"/>
<input checked="" type="checkbox"/>	/r1504	Level	0	1000	m	<input type="checkbox"/>
<input checked="" type="checkbox"/>	/r1511	Flow	0	100	m3/h	<input type="checkbox"/>
<input type="checkbox"/>						<input type="checkbox"/>
<input type="checkbox"/>						<input type="checkbox"/>
<input type="checkbox"/>						<input type="checkbox"/>
<input type="checkbox"/>						<input type="checkbox"/>

The template configuration table displays the following information for each report's item:

- Active** – Check to display the item.
- Path** – Item variable path. The full item path will build from the report offset path as a prefix and the item variable path. For example: if the report offset path = /icex1 and offset = check and item variable path = r1501 then the online item full path will be: /icex1/r1501.
- Description** – The item description will appear at the header row of the report.

**Minimum, Maximum** – Define the item axis limit in trend display.

**Unit** – Define the item unit to display in the item trend legend.

**Axis** – Check to display item axis in trend display.

Buttons:

**Return** – Return to the edit reports menu

**Import** – Import templates from a text file. You can use this option to restore the templates from a backup text file.

**Export** – Export the template to a text file for backup, text edit or for sharing setting with other users.

**Add** – Add template.

**Delete** – Delete current template.

**Save** – Save template changes to local storage

**Bottom bar navigate toolbar** – Next, pervious and select list to navigate between the template.

## 13. Edit project nodes

There are three types of nodes:

- **Group** - Group of nodes.
- **Point** - a variable or computed value.
- **Alarm** - unit or computed alarm node.

Property	Value
Type	Point
Offset	/
Path	source
Tag-name	Tag-name
Description	Description
Active	<input checked="" type="checkbox"/>
Visible	<input checked="" type="checkbox"/>
Source	
Source-mode	reflect
Sample-rate	60
Filter	
Scale-source	
Scale-target	
Format	
Writeable	<input checked="" type="checkbox"/>
Write-range	
History	<input type="checkbox"/>
Update-URL	

Return Apply Duplicate Alarm + Point + Group + Delete

Previous Next

Node properties:

**Type** – Node type: Group, point, alarm. Read-only.

**Offset** – The node path offset initialize with the node group path. The full node path is a result of the offset field as a prefix and the variable filed.

**Path** – Variable path. One word, only standard letters and numbers are allowed. For names of variable nodes use the unit addresses space as specified in the appendix.

**Example:** Offset field = /icex/variable/, variable = r1501 the full node path will be /icex/variable/r1501

**Tag-name** – Node tag-name. Normally one word that describing the node. Like: TE1101 for temperature element 1101 or LS2314 for level switch 213.

**Description** – Node description.

**Active** – Default checked, un-checked: the node will not update. The COMP will not subscribe the node for updating.

**Visible** – Default checked: always display. Un-checked: display node only if user login as administrator.

**Source** – Default empty. Node values can be computed from others node value. Examples:

- {/analog/r1401} + {/analog/r1402} - Node value will be sum of r1401 and r1402. Remark node path must be close with patterns
- {/analog/r1401}[3] - Node value will be the status of bit 3 of r1401. Bits count start form zero (0).
- {/analog/r1401} [3] = 1 or {/analog/r1401}[3] >= 80 - Node value will be the boolean result of the source expression.

For more details see the appendix.

**Source Mode** – Default reflect. Reflect/Transfer. Reflect – reflect value of source expression, Transfer - transfer (whenever value change) value of source expression to producer who owns the node.

**Sample Rate** – Default 60. Set the node sample rate in a second. Normally 10 seconds for alarms and 60 second and above for other variables.

**Filter** – Default empty. Node's value filter used by the unit when update the node value. Adjust sample rate and filter to get the optimal network traffic. For more details see the appendix.

**Scale-source** – Default empty. Source to target scaling. Example: 0..4095 to 0..100.

**Scale-target** – Default empty. Source to target scaling. Example: 0..4095 to 0..100.

**Format** – Default empty. Display format. Example:

- %2.1f - 23.5.
- %2.1f psi – 23.5 psi

For more details see the appendix.

**Writeable** – Default unchecked. Checked: Node's value can be modifying by user.

**Write range** – Default empty. Limit the user write range. Example: 40..50.

**History** – Default unchecked. Checked: Keep Node value changes to history. Also keep user node value change.

**Acknowledgment** – Default unchecked. Checked: alarm node need user acknowledgement.

**Alarm Recipients** – Default empty. List of SMS/Email alarm recipients separate by comma.

**URL Updates** - Default empty. URL address for online node state updates.

The UI includes an interface for changing setting of individual node or group of nodes. The COMP will update the setting of the group and its sub-nodes according to the marked properties. The COMP will update the node owner (Producer) "on the fly" with the updated properties.

Apply	Property	Value
	Type	Group
	Offset	/
	Path	
	Tag-name	
	Description	Home
<input type="checkbox"/>	Active	<input checked="" type="checkbox"/>
<input type="checkbox"/>	Visible	<input checked="" type="checkbox"/>
<input type="checkbox"/>	Source	
<input type="checkbox"/>	Source-mode	reflect

When you edit a group node, you can apply specific fields change to all the group sub-node. The apply button effect only the group itself, by checking the necessary apply check-box and clicking the "apply all" button the setting in the check rows will affect the group and its sub-nodes too.

Buttons:

**Return** – Return to the main edit menu

**Apply** – Apply the edit function.

**Apply all** – It appears only for group modify. Apply the selected rows to the group and its sub-nodes.

**Duplicate** – Duplicate the current display node under the current offset.

**Alarm +** – Add alarm under the current offset.

**Point +** – Add point under the current offset.

**Group +** – Add group under the current offset.

**Delete** – Delete the current display node.

**Next, Pervious** – Navigate between group nodes. To edit a specific node or group use the tree display to select and display the necessary node.

## 14. Edit Users

Edit user's privilege and details.

Return					Group +	User +
Del	Name	Title	Kind	Group		
del	david	David Cohen	user			
del	default		default			
del	icex	icex	user			
del	sms	David Cohen	user			

The user configuration table displays the following information for each user:

**Name** – User or unit name.

**Title** – User title \ description, editable.

**Kind** – user kind: default, user or group.

**Group** – User privileges group. You can create users group set the group privilege and later just assign user to a group.

Buttons:

**Return** – Return to the main menu.

**Group +** – Add user group. Open a dialog box for entering the new group name.

**User +** – Add user. Open a dialog box for setting the new user name and password.

**Delete** – Remove user and its privileges and properties.

**Remark:** create a user entry for each unit you want to connect to the system and set the privilege to write, read and config on the unit path. Before creating the unit entry, you should first have to create the unit path. Click on the user name switch to edit user privileges and properties window.

Return
Permission +
Password
Schedule

User : sms - Title: David Cohen

Permissions :

Del	path	Read	Write	Modify	Config
del	/icex	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>

Email Address(es) :

SMS phone number(s) :
0523249377

SMS schedule :

Day	Start	End
Sunday	7:00	17:00
Monday	10:00	16:00
Tuesday		
Wednesday		
Thursday		
Friday		
Saturday		

Buttons:

**Return** – Return to users edit window.

**Permission +** – Add a permission row. Add button opens a dialog box for entering the permission path like: "/" for project root or "/icex" for a unit path. Permission includes: Read – Checked - User allows reading path items value.

**Write** – Checked - User allows modifying path item value.

[www.RealiteQ.com](http://www.RealiteQ.com) - [Realinfo@RealiteQ.com](mailto:Realinfo@RealiteQ.com) - T: +972-9-7494000 – F: +972-9-7494774

**Modify** – Checked - User allows modifying path item properties.

**Config** – Checked - User allows modifying item's properties, adding and deleting an item.

For project administrator configuration: Path to "/" and check read, write and config option. For unit configuration: Path to unit path "/unit path" and check read, write and config options.

**Password** – Open a dialog box for replacing user password.

**Schedule** – Update COMP with the SMS schedule.


**Email address(es)** – Enter emails addresses separated by commas for receiving email alarm messages. The RealiteQ-COMP will send alarm messages if the user's name appears in the recipients list. Click enter key to apply.

**SMS Phone numbers** – Enter phone numbers separated by commas for receiving alarm messages as SMS messages. The RealiteQ-COMP will send alarm messages with the recipient phone numbers to the iCex SMS center if the users name appears in the recipients list. Click enter key to apply.

**SMS schedule** – No start and stop hour set, the system will send SMS all day. If you set: start = 08:00 and end = 17:00 the system will send SMS to the user only between 08:00 to 17:00. If you set start = 17:00 and stop = 08:00 the system will send Alarm SMS messages between 00:00 to 08:00 and between 17:00 to 24:00. Click Schedule button to apply.

## 15. Draw editor

The draw template editor included in RealiteQ UI simplifies project draws design by providing a rich set of drawing and manipulation tools. Changes to object appearance and placement can be applied easily using the link properties panels. You can switch between a design mode and operator mode with a single key-stroke.



Designing draw is a process which involves two stages:

Prepare and place the screen background. The background is an import JPG or PNG format picture.

Locate the links on the screen background. The elements can be schematic or figurative and can also incorporate text or value.

Use links to modify the graphical elements at runtime in correspondence to changes in real-time values.

For setting the links stage, RealiteQ UI offers a comprehensive suite of tools in order to make the process of screen design as easy and fast as possible. How to ties the draws template to the screens **see paragraph 11**.

15.1 Draw menu

15.2 Background image

## 16. Upload to COMP

The modern browser allows web applications to synchronize data into a local data store (Local storage) and then allow the web applications to use this data online. The UI application use this features to keep the user project setting locally. The project managers normally prepare the general project screens and reports and upload them to the COMP. The project UI clients can now at any time download the project setting to their browser local storage.

Return Apply

Project upload to COMP from local-storage

Description	Active
Map	<input type="checkbox"/>
Reports	<input type="checkbox"/>
Templates	<input type="checkbox"/>
Screens	<input type="checkbox"/>
Draws	<input type="checkbox"/>

### Notes:

- Only user with administrator privilege can upload the project to the COMP.
- User will need to load the settings once, only the first time you log in to the project.
- All the further user modification affects only his project setting in his browser local storage.
- Each project saves in a different local storage. (There is private storage for each URL).

Always keep the export backup of your private project setting.

### Upload

**Map** – Upload map center, map type and unit's path, location and description.

**Reports** – Upload reports/trends template and reports/trend list.

**Screens** – Upload screens template and screens list.

**Draws** – Upload screens design.

To upload set the necessary option and then apply.



## Appendixes

### 1. Address space

The iCEX supports a wide variety of data representations for PLC variables. The general address format recognized by the iCEX is: <type><memory offset>. Memory offsets are in the range 0 to 65565. For individual bits the format changes to R<memory offset><bit offset>, where <bit offset> is a number between 1 and 16. The following address types are supported for Modbus:

I	Input (Modbus opcode 02)
O,B	Output and internal flags (Modbus opcodes 01/05)
R	16-bits register (Modbus opcodes 03/06)
D	32-bits register (Modbus opcodes 03/0x10)
F	32-bits floating point (Modbus opcodes 03/0x10)
A	16-bits analog input (Modbus opcode 04)
L	32-bits analog input (Modbus opcode 04)
N	32-bits floating analog input (Modbus opcode 04)

The following address types are supported for GE SNPX:

I	Input
O	Output
B	Internal flags
R	16-bits register
D	32-bits register
F	32-bits floating point

The following prefixes can be added before the type:

U	Unsigned value (by default integer values are signed)
X	Value is stored in BCD format

Examples:

1. R1000 - 16-bit signed integer at offset 1000.
2. XR1000 - 16-bit BCD integer at offset 1000.

## Stations

If multiple PLC's are connected to the iCEX (using RS-485), they can be accessed by creating groups for each. The iCEX recognizes subgroups with their name formatted as st<station id>. For example, **st4** refers to a PLC with station ID 4. The iCEX will sample all sub-nodes within the subgroup, e.g. st4/r1028, from the corresponding PLC.

## 2. Filter

iCEX supports a variety of dead-band types in order to provide a rich set of filters for unstable measurements:

Type	Example	Behavior
None	(empty)	Value is always transmitted to the server.
Never	never	Value is transmitted only when forced by status/b12
Value	2.5	Value is transmitted if change is greater than the specified value.
Percentage	%3	Value is transmitted if change is greater than the specified percentage.
Greater than	>10	Value is transmitted if it is greater than the specified value.
Greater than or equal	>=10	Value is transmitted if it is greater than or equal to the specified value.
Less than	<10	Value is transmitted if it is less than the specified value.
Less or than equal	<=10	Value is transmitted if it is less than or equal to the specified value.
In range	8<>12	Value is transmitted if it is within the specified value range.
Out of range	8><12	Value is transmitted if it is outside of the specified value range.
Equal	=8.5	Value is transmitted if it is equal to the specified value.
Out of range	<>8.6	Value is transmitted if it is not equal to the specified value.

### 3. Formats

Format specifiers have the following form: "%" ["-"] [width] [". " prec] type

A format specifier begins with a % character. After the % come the following, in this order:

- An optional left justification indicator, ["-"].
- An optional width specifier, [width].
- An optional precision specifier, [". " prec].
- The conversion type character, type

The following table summarizes the possible values for type:

d, i	Decimal. The value is converted to a string of decimal digits. If the format string contains a precision specifier, it indicates that the resulting string must contain at least the specified number of digits; if the value has fewer digits, the resulting string is left-padded with zeros. Like %4d => ' 34'
u	Unsigned decimal. Similar to 'd' but no sign is output.
e	Scientific. The value is converted to a string of the form "-d.ddd...E+ddd". The resulting string starts with a minus sign if the number is negative. One digit always precedes the decimal point. The total number of digits in the resulting string (including the one before the decimal point) is given by the precision specifier in the format string—a default precision of 15 is assumed if no precision specifier is present. The "E" exponent character in the resulting string is always followed by a plus or minus sign and at least three digits. Like %1.3e => '1.263 E+3'
f	Fixed. The value is converted to a string of the form "-ddd.ddd...". The resulting string starts with a minus sign if the number is negative. The number of digits after the decimal point is given by the precision specifier in the format string—a default of 2 decimal digits is assumed if no precision specifier is present. Like %2.1f bar => '15.1 bar'
g	General. The value is converted to the shortest possible decimal string using fixed or scientific format. The number of significant digits in the resulting string is given by the precision specifier in the format string—a default precision of 15 is assumed if no precision specifier is present. Trailing zeros are removed from the resulting string, and a decimal point appears only if necessary. The resulting string uses fixed point format if the number of digits to the left of the decimal point in the value is less than or equal to the specified precision, and if the value is greater than or equal to 0.00001. Otherwise the resulting string uses scientific format.
n	Number. The value is converted to a string of the form "-d,ddd,ddd.ddd...". The "n" format corresponds to the "f" format, except that the resulting string contains thousand separators. Like %5.2n => '1,234.45'
x	Hexadecimal. The value is converted to a string of hexadecimal digits. If the format string contains a precision specifier, it indicates that the resulting string must contain at least the specified number of digits; if the value has fewer digits, the resulting string is left-padded with zeros. Like %04x => '0A45'
o	Octal. The value is converted to a string of octal digits. If the format string contains a precision specifier, it indicates that the resulting string must contain at least the specified number of digits; if the value has fewer digits, the resulting string is left-padded with zeros. Like %04x => '0745'
b	The value is converted to a string of zeros and ones of binary number. Like %08b => '00101101'

A width specifier sets the minimum field width for a conversion. If the resulting string is shorter than the minimum field width, it is padded with blanks to increase the field width. The default is to right-justify the result by adding blanks in front of the value, but if the format specifier contains a left-justification indicator (a "-" character preceding the width specifier), the result is left-justified by adding blanks after the value.

## 4. Source field

You can write any expression using mathematical operators and constants (strings, numbers and booleans). String constants are given using single or double quotes. Real-time point values can be referenced using curly brackets, for example:

```
{/icex1/r412}
{/icex1/r412} + {/icex1/r413}
"R414:" + {/icex1/r414}
{/icex1/r412} >= {/icex1/r413}
{/icex1/r412}[1] && {/icex1/b20}
```

Here is a list of the arithmetical operations that can be used in source filed

+	addition
-	subtraction
*	multiplication
/	division

In order to evaluate a comparison between two expressions you can use the relational and equality operators. The result of a relational operation is a Boolean value that can only be true or false, according to its Boolean result. You may want to compare two expressions, for example, to know if they are equal or if one is greater than the other is. Here is a list of the relational and equality operators that can be used in source filed:

==	Equal to
!=	Not equal to
>	Greater than
<	Less than
>=	Greater than or equal to
<=	Less than or equal to

Here is a list of the Boolean operations that can be used in source filed

!	Perform the Boolean operation NOT. It returns the opposite Boolean value of evaluating its operand.
	Boolean logical operation OR. This operation results true if either one of its two operands is true.
&&	Boolean logical operation AND. This operation results true if both its two operands are true.

Bits can be referenced by using the standard array subscript notation (with bits starting at 0):

```
{/icex1/r412}[0]
```

```
{/icex1/r412}[1] || !{/icex1/r412}[2]
```

Also supported are functions for converting types:

```
{/icex1/r412}.to_s => converts to string
```

```
{/icex1/r412}.to_bool => converts to boolean
```

```
{/icex1/f412}.to_i => converts to integer
```

Boolean expressions are also possible, especially useful for alarms:

```
{/icex1/r412} > 50
```

Also supported is a special system object which supplies global information. Currently only `system.time` is supported:

`system.time` => the current system time of the server